





Installation instruction





Premodul






4


5




6




7 Ci5




7 Ci4




8




9




10






11



12




Ci5




Ci4


13




13



14




15




Ci5

16a




16b




Ci4

16.1



16.2



Premodul

NIBE AB · Box 134 · SE-285 23 Markaryd · Sweden
www.contura.eu

Contura reserves the right to change dimensions and procedures described in these instructions at any time without special notice. The current edition can be downloaded from www.contura.eu